


Touch-Plate® Lighting Controls


5400 & 5600 Series / Low Voltage Switches

The 5400 and 5600 Series:


The Touch-Plate 5400 and 5600 Series Switches are newly updated and available in either 4 or 6 buttons for master control locations. The plastic cover attaches into mounting holes with no exposed screws. These switches are designed for use with any new low voltage control system and are exact replacements for switches in older Touch-Plate lighting control systems.




5404




5408




5412



5606



5612



5618

Features:

- Plastic covers are standard
- May be used with Flushplate metal plates and frames
- 5400 & 5600 switches are non lit
- Same design as CCN Series
- 2 wire momentary push button switch
- One, two, or three gangs in a single wall plate
- Switch contacts rated 1 amp @ 28 volts
- Simplified wiring to labeled terminals
- Caps can be engraved

Ordering Information:

The catalog number guide below illustrates the variations available and establishes the components to build a catalog number for ordering purposes. To order, select the switch number for your application and follow the example shown below. * Granite and Black covers available in single gang versions only.

